## **FAQ**

- FOR MKS V1.1 Firmware Refresh (up-date)
- Heating head Adjusting the PID
- Hot bed PID adjustment method
- Computer and printer USB connection
- Motor direction and motor current modification

Motor direction and motor current modification










# **Adjusting the PID**

The PID value has been set at the factory, and there is no need to modify it by default. If the temperature fluctuates greatly, or a temperature error occurs during operation, please modify it as follows.

### Command head heating target: M303 E0 C8 S230

- E0 Nozzle heating block
- C8 Number of Detection frequency
- S230 is the head heating target temperature of 230°C.

( Reference Nozzle value: PLA- 195 °C ABS-230 °C )



#### Command hot bed: M303 E-1 C8 S50


- E-1 Hot bed
- C8 Number of Detection frequency
- S50 Is the target temperature of the hot bed
   ( Reference Hot bed value: PLA- 50 °C ABS-80 °C )



Ensure safety, the maximum temperature has been set in the firmware Nozzle temperature cannot be higher than 250 °C

Hot bed temperature cannot be higher than 110°C


the hot bed has been set in the firmware not higher than 80 ° C. Hot-bed magnetic stickers are not recommended for long-time work above 80 ° C. If 110 °C is needed, please modify the maximum temperature of the firmware hot bed



### FOR MKS V1.1 Firmware Refresh(up-date)








Open the lite\_cfg file with Notepad

Download the latest firmware https://github.com/my3dltd/F1-MKS-V1.1-Firmware



Modify the corresponding value Such as motor direction PID WIFI, etc.





Copy the modified lite cfg file and mkslite.bin to the TF card, insert the 3D printer, And then turn on the power switch again. Will update automatically.

After the update, the files in the TF card are automatically invalidated (can be deleted) and can only be updated once. If you need to update again. Pls re-copy the file into the TF card.

First connect the pc and printer with usb cable



Turn on the power switch



 Open the host computer software (RepetierHost or Pronterface, etc.) to connect to the printer.

Pronterfac `` <a href="http://www.pronterface.com/index.html#download">http://www.pronterface.com/index.html#download</a> `` Repetier-Host `` <a href="https://www.repetier.com/">https://www.repetier.com/</a> ``


When the connection is wrong, please turn off the printer power, reconnect the USB connection, and then turn on the printer power switch again.

Normal heating print waiting time (tested at 25 ° C Room temperature)
PLA heating head 195 ° C hot bed 50 ° C usually starts printing for 3-5 minutes
ABS heating head 260 ° C hot bed 80 ° C usually start printing 5-7 minutes
F1-A F1-B (24v 350w 110/220v) Power of hot bed: 200-250W Heating head power: 50w

# **Heating head Adjusting the PID**

The PID value has been set at the factory, and there is no need to modify it by default. If the temperature fluctuates greatly, or a temperature error occurs during operation, please modify it as follows.

Send the code "M303 E0 C8 S250" to the printer in the host computer software.






- E0 Nozzle heating block
- C8 Number of Detection frequency
- \$230 is the head heating target temperature of 230°C.

#### ! PID Autotune failed! Temperature too high

Please check the temperature protection setting in the firmware


#### When the connection is wrong,

- 1. please turn off the printer power,
- 2. reconnect the USB connection.
- 3. and then turn on the printer power switch




Update the firmware file in lite\_cfg.txt Type of heat manager for extruder. Kp KI Kd Click to see how to modify the updated PID value in Lite——cfg.txt file

Write the Extruder PID parameter to the following part of the "lite\_cfg.txt" file.



# Hot bed PID adjustment method:

Send the command: M303 E-1 S50



#### PID Autotune failed! Temperature too high

Please check the temperature protection setting in the firmware

#### When the connection is wrong,

- 1. please turn off the printer power,
- 2. reconnect the USB connection,
- 3. and then turn on the printer power switch

the hot bed has been set in the firmware not higher than 80  $^{\circ}$  C. Hot-bed magnetic stickers are not recommended for long-time work above 80  $^{\circ}$  C.

If 110  $^{\circ}\text{C}$  is needed, please modify the maximum temperature of the firmware hot bed.


Reference Hot bed:


PLA- 50 °C M303 E-1 C8 S50 ABS-80 °C M303 E-1 C8 S80



- E-1 Hot bed
- C8 Number of Detection frequency
- \$50 Is the target temperature of the hot bed

Click to see how to modify the updated NEW PID value in Lite——cfg.txt file





Congratulations
Set up successfully





## Motor direction and motor current modification

If you modify the rotation direction, you can directly modify it to 0-1 or 1-0

```
#Set stepper current
>CURRENT VREF XY
                        1200
                                #Default motor current for XY in mA, range (0~1500)
>CURRENT VREF Z
                        1200
                                #Default motor current for Z in mA, range (0~1500)
>CURRENT VREF E
                        1500
                                #Default motor current for E in mA, range (0~1500)
#Invert the stepper direction.
>INVERT X DIR
                        0
                                 #If you modify the rotation direction, you can directly modify it to 0-1 or 1-0
>INVERT Y DIR
                                 #If you modify the rotation direction, you can directly modify it to 0-1 or 1-0
                       0
INVERT Z DIR
                                 #If you modify the rotation direction, you can directly modify it to 0-1 or 1-0
>INVERT E0 DIR
                                 #If you modify the rotation direction, you can directly modify it to 0-1 or 1-0
```

### View firmware update method

Download address of firmware (after decompression-do not re-name lite cfg.txt mksLite.bin file name)

https://github.com/my3dltd/F1-MKS-V1.1-Firmware



https://github.com/my3dltd/F1-MSK-V1.1-WIFI